R95 1840 - Particulate Welding Respirator with Valve

PRODUCT SHEET

NIOSH Approved R95 Particulate Respirator provides at least 95% filtration efficiency against solid and liquid aerosols, including oil based aerosols. Recommended for welding applications.



KEY FEATURES

- Larger Comfort-Maxx[™] valve opens more easily to expel hot, humid breath and keep inside of the respirator cooler and more comfortable
- Full foam inner gasket helps provide a good seal and is comfortable to wear
- Adjustable headstraps
- Flame retardant
- Collapse resistant double-shell construction

Louis M. Gerson Co Inc. MIDDLEBORO, MA 1-800-225-8623 This cartridge is approved only in the following configurations:			
TC-	Protection ¹	Respirator	Cautions and Limitations ²
84A-0383	R95	1840	ABCJMNOP

¹ PROTECTION

R95 Particulate filter (95% filter efficiency level) effective against particulate aerosols; time use restrictions may apply.

² CAUTIONS AND LIMITATIONS

- A Not for use in atmospheres containing less than 19.5 percent oxygen.
- ${\sf B}$ Not for use in atmospheres immediately dangerous to life or health.
- C Do not exceed maximum use concentrations established by regulatory standards.
- J Failure to properly use and maintain this product could result in injury or death.
- M All approved respirators shall be selected, fitted, used, and maintained in accordance with MSHA, OSHA and other applicable regulations.
- N Never substitute, modify, add, and, or omit parts. Use only exact replacement parts in the configuration as specified by the manufacturer.
- O Refer to user instructions, and/or maintenance manuals for information on use and maintenance of the respirators.
- P NIOSH does not evaluate respirators as surgical masks

NOTE: Before occupational use of this respirator a written respiratory protection program must be implemented meeting all the local government requirements. In the United States employers must comply with OSHA 29 CFR 1910.134 which includes medical evaluation, training and fit testing.

WARNING: This product does not provide any lung protection against organic vapors or acid gases. Do not use in or around sandblasting. This product does not supply oxygen. Read and Understand Instructions and Warnings before using this product.



16 Commerce Blvd., Middleboro, MA 02346 U.S.A. Tel (508) 947-4000 • Sales@GersonCo.com • www.GersonCo.com